



EzCabling

Lite Trace Fibre Optic Leads

Features:

- ⇒ Cable types
 - OM3 Multimode
 - OM4 Multimode
 - OS2 Single Mode
- ⇒ LSZH Sheath
- ⇒ Uni-Boot Construction
- ⇒ Monotube
- ⇒ Connector types

LC	LC/APC
SC	SC/APC
ST	FC
MTP / MPO	

Unique Features:

Lite Trace

Attach the Trace Tester tool to the local/known end of the lead, turn the power on and both the local/known and remote/unknown end will light up

Push the Power Button and it will toggle between two modes, constant and flashing

LC –EZ Release

LC High Density application are always a tight fit, with Lite Trace's LC-EZ Release handle, simply lift the handle & this will lever the standard connector tabs & release the cables


Description:

Looking for an easy method to trace your network connections in your crowded Data Centre or Equipment Cabinet infrastructure?

The answer is *LiteTrace Leads!*

Simply attached our Trace Tester tool to the rear of our *Lite Trace Lead* & we'll light the way


Fits with industry standard patch panels, network switches & Interface equipment



Part Number Breakdown

Product Series	Lite Trace
Cable mode OM1 / OM3 / OM4 / OS2	OM4
Connector Types :	LC
L=LC/LA=LCA/C=SC/CA=SCA/T=ST/F=FC/M=MTP	LC
Cable Length in metres	1 metre
Sheath Colour	Aqua

LTOM4LL1AQ






1300 850 787

info@ezcabling.com.au

ezcabling.com.au



EzCabling




Uni-boot design
 ✓ Reduce cable pathway congestion
 ✓ Simplifies cable management
 ✓ For high density data center applications and blade


Patent-pending magic tab
 ✓ Use seesaw idea
 ✓ Can be disengaged easily and fast

LED-lighted plugs
 ✓ Clearly visible from several metres


Flexible polarity change
 ✓ Clear identification with polarity A and B
 ✓ Easy to change
 ✓ Particular housing design eliminates potential connector and cable damage



To extract LC Connector using LC-EZ Release



To change Polarity





1300 850 787
 info@ezcabling.com.au

ezcabling.com.au




EzCabling

Tracing Tester User Guide



Rest tool folder between thumb and forefinger.



Insert the folder in the end of boot, press folder against the boot slightly.